UK

## Product information







**A**: Card insertion symbols
**B**: Rubber feet
**C**: Velcro tape
**D**: Activity indicator
**E**: Power indicator
**F**: Slot: CF I, CF II, MD
**G**: Slot: XD
**H**: Slot: SMC SM-RAM
**I**: USB port
**J**: Slot: MS, MS pro, MS-Duo, MS-Pro Duo (MS-MG) MS Select
**K**: Slot: SD, Mini SD, MMC, RS-MMC

## Installation

**1**

Use rubber feet for use on desk
**Or** → 2

**2**

Use Velcro tape

**3**

Windows XP/2000/ME/XP 64bit/MCE
Windows 98 SE→ 5

**4**



**Windows XP/2000/ME/64bit/MCE**
Connect card reader

**5**




Computer on

⚠ Wait until automatic installation is finished.

**Windows 64 bit: Finish**

**6**

Place CD in CD-ROM

UK

| | | |
|---|---|---|
| 7 |  | Install driver |
| 8 |  | Select Language<br>Next (2x) |
| 9 |  | 1) Yes, I want to restart my computer now.<br>2) Finish → Computer restarts<br>3) Windows XP/2000/ME/MCE → 11<br>Windows 98 SE→ 10 |

**10**



**Windows 98 SE**
Connect card reader

**11**

Indicator (E) lights
Finish (card reader is ready for use)

**Card type icons**




D: CF or MD
E: SMC, SM- RAM
F: SD, Mini SD, MMC, RS-MMC
G: MS, MS pro, MS-Duo, MS-Pro Duo (MS-MG), MS Select.
H: XD card

⚠ Drive letters might differ, depending on users system

⚠ Windows 98 SE and XP 64 bit: standard drive names







CF or MD
1. Insert card
2. Active LED (D) lights
3. Drive icon pops up coloured

UK



SMC or SM-RAM
1. Insert card
2. Active LED (D) lights
3. Drive icon pops up coloured







XD
1. Insert card
2. Active LED (D) lights
3. Drive icon pops up coloured







SD, Mini SD, MMC, RS-MMC
1. Insert card
2. Active LED (D) lights
3. Drive icon pops up coloured
⚠ Use adapter for Mini SD and RS-MMC cards







MS, MS pro, MS-Duo, MS-Pro Duo (MS-MG) , MS Select

1. Insert card
2. Active LED (D) lights
3. Drive pops up coloured

⚠ Use adapter with MS (pro) duo cards

**Reminders**

⚠ Place card into the reader in a wrong direction may cause damage to the device

⚠ Don't force a card into a slot when it does not fit in

⚠ If you format a card on your computer and then use it in your digital camera or other portable device, the device may no longer recognize the format of the card. It is, therefore, recommended to always format the card using your digital camera or the portable devices

⚠ Check if it's write protected when you are not able to copy data to a card

⚠ If you experience intermittent problems after Windows resumes from sleep, hibernation or computer inactivity: go to Device Manager > Universal Serial Bus Controllers > USB Root Hub > Power Management, Uncheck the box "Allow computer to turn off this device to save power". Uncheck all boxes on all root hubs

⚠ Do not remove a card when the active indicator (D) is still blinking otherwise the data may not be read or written correctly

⚠ Memorystick (pro) duo, RS-MMC and mini SD needs adapter for using in cardreader.

⚠ Inappropriate use may result in the loss of your data. Trust is not directly or indirectly responsible for this.

⚠ Power indicator (E) only lights after Windows (driver) has recognised cardreader.

⚠ Activity indicator (D) lights during reading/writing, or errors.

⚠ Always remove cards in safe removal mode

⚠ Cards supported:

| Type | Size | Type | Size | Type | Size | Type | Size |
|---|---|---|---|---|---|---|---|
| SMC | 8MB ~ 128MB | CF II | Up to ~ 2.0GB | MMC | Up to ~ 256MB | MS Pro | Up to ~ 1GB |
| RS-MMC | Up to 256MB | MD | up to ~ 2.2GB | Mini SD | Up to ~ 512MB | MS Duo | 64MB, 128MB |
| CF I | Up to ~ 1GB | SD | 32MB ~ 512MB | MS (MG) | 64MB ~ 128MB | MS-Pro Duo | Up to ~ 1GB |
| XD | Up to ~ 512 MB | SM-RAM | 8MB ~ 128MB | MS Select | 256 MB | | |

Due to the continuous development of memory card capacity, it can be possible that cards with a higher capacity than mentioned are supported.

If you have any problems, go to www.trust.com/14326 for FAQ, drivers and manuals.

**Safety**

- Do not repair this device.
- Keep this device away from liquids, such as water.

CE

- This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at www.trust.com/14326/ce

**Warranty & copyright**

- This product has a two-year manufacturer's warranty which is effective from the date of purchase. For more information see www.trust.com/warranty
- Reproduction of this manual or any part of it is prohibited without permission from Trust International B.V.